

For Aluminum Spa Covers Only

1. Follow Pre-Assembly instructions up to step #4.
2. Ignore Pre-Assembly Step #4 and #5.
3. Slide the Stabilizer Sleeves (cvH) over the Stabilizer Bards (cvFF).
4. Follow all instructions from Pre-Assembly #6 up to step #10.
5. Ignore Step #10.
6. Remove the existing top screws on the sides of your Aluminum Spa Cover and discard.
7. Align the holes in the Aluminum Extension Arms with the holes in the side of the Aluminum Spa Cover and attach using the new screws provided.
8. Follow instructions #11, #12, and #13.
9. Ignore Step #14.

